

HAVING PROBLEMS WITH CORNERING AND HANDLING?

USE HELLWIG'S SWAY BAR KITS AND YOUR PROBLEMS GO AWAY.



Sway Bars are the easiest, most cost effective way to improve your vehicles cornering and handling performance.

Reduces body roll so you benefit from better vehicle control

Greatly improved cornering traction for safer driving

YEAR	APPLICATION	FRONT KIT		REAR SWAY BAR		LARGER DIAMETER: <i>Big Wig Rear Kit</i>	
		PART #	DIAMETER	PART#	DIAMETER	PART #	BAR DIAMETER
GM							
01-06	2500/3500 HD	7654	1-1/2"	7652	1 1/4"	7269	1 5/16
07-10	2500/3500 HD	7654	1-1/2"	7664	1 1/4"	7267	1 5/16
07-11	1500 Silverado, Sierra Pickup 2wd & 4wd	7685	1-1/2"	7800	1 1/8"		
11-12	2500, 3500 HD Pickup 2wd & 4wd	7716	1-1/2"	7717	1 1/4"	7270	1 5/16
FORD							
99-04	F250-F350 Super Duty Single Wheel Pickup 2WD	7640	1-1/2"	7677	1 1/4"	7268	1 5/16
				Uses Factory End Links or use 7973.for replacment			
05-07	F250-F350 Super Duty Single Wheel Pickup 2WD	7674	1-1/2"	7677	1 1/4"	7268	1 5/16
08-10	F250-F350 Super Duty Single Wheel Pickup 2WD			7677	1 1/4"	7268	1 5/16
99-04	F250-F350 Super Duty Single Wheel Pickup 4WD	7640	1-1/2"	7677	1 1/4"	7268	1 5/16
				Uses Factory End Links or use 7973.for replacment			
05-07	F250-F350 Super Duty Single Wheel Pickup 4WD	7676	1-1/8"	7677	1 1/4"	7268	1 5/16
				Uses Factory End Links			
08-10	F250-F350 Super Duty Single Wheel Pickup 4WD	7690	1-1/4"	7677	1 1/4"	7268	1 5/16
				Uses Factory End Links			
09-12	F150 2wd & 4wd	7704	1-1/2"	7705	1 1/8"		
11-12	F250, 350 4wd	7712	1 5/16	7714	1 1/8"	7271	1 1/4
DODGE							
03-08	2500/3500 w/5.9 Diesel	NA	NA	7658	1 1/8	7265	1 5/16
03-09	2500/3500 w/6.7 Diesel	NA	NA	7703	1 1/8	7266	1 5/16

EZ-990 & PRO SERIES

LEVEL YOUR LOAD

EZ-990

Amazing load capacity for the price!

2,000 lbs level load capacity!

Can be adjusted independently for uneven side to side loads

Mounts under U-bolt plates

Step bracket style also available!

PRO SERIES

2,500 lbs level load capacity!

Progressive rate leaves do not effect the ride when unloaded

SILENT RIDE FEATURE



EZ-990



PRO SERIES



**Pro Series come in a Hammer Tone Coat finish*

EZ-990 APPLICATIONS

YEAR	APPLICATION	PART #
DODGE		
70-93	D100-150 Pickup 2wd & 4wd	991
94-02	1500 ram pickup 2wd & 4wd	994
03-08	1500 ram pickup 2wd & 4wd	982
70-03	B-100, B150 Van	991
FORD		
72-96	F100-F150 2X4 & 4X4 Pickup (2)	991
97-03	F-150 Pickup & Super Crew (2)	991
04-08	F-150 (Except Heritage Edition) (1)	984
09-12	F-150 (Except Heritage Edition) (1)	989
83-09	Ranger 2WD & 4WD	983
75-11	E100,E-150 Van (2)	991
GM		
63-87	C/K 10 Pickup 2WD & 4WD (2)	991
88-98	C/K 10, C/K1500 Pickup 2WD & 4WD	985
99-06	C/K 10, C/K1500 Pickup 2WD & 4WD	986
07-12	1500 Pickup 2WD & 4WD (1)	987
72-07	G10,G1500 Van (2)	991
MAZDA		
94-07	B2300,B4000	983
NISSAN		
04-11	Titan	988
TOYOTA		
05-11	Tacoma 4WD	981
00-06	Tundra (2)	991

PRO SERIES FULL SIZE PICKUP AND VAN

YEAR	APPLICATION	PRO-SERIES
CHEVROLET/GMC FULL SIZE PICKUP & SUV		
01-06	C2500 LD 2WD,4WD P/U	61901
01-10	2500 HD 2WD,4WD P/U	61901
01-10	3500 HD 2WD,4WD P/U	61906
11-12	2500, 3500 Call for LP25, LP35 Applications	
FORD FULL SIZE PICKUP & SUV		
99-04	F250/F350 Super Duty 2WD Single Rear Wheel	61904 (1)
99-04	F250/F350 Super Duty 4WD Single Rear Wheel	61904 (1)
05-07	F250/F350 Super Duty 2WD Single Rear Wheel	61904 (1)
05-07	F250/F350 Super Duty 4WD Single Rear Wheel	61904 (1)
05-07	F250/F350 Super Duty 2WD Single Rear Wheel	61904 (1)
	w/ Factory Contact Overload	
05-07	F250/F350 Super Duty 4WD Single Rear Wheel	61904 (1)
	w/ Factory Contact Overload	
08-10	F250/F350 Super Duty 2WD Single Rear Wheel	61901 (1)
08-10	F250/F350 Super Duty 4WD Single Rear Wheel	61901 (1)
99-07	F250/F350 Super Duty 2WD/4WD Dually	61904 (1)
08-10	F250/F350 Super Duty 2WD/4WD Dually	61901 (1)
11-12	F250, 350 Call for LP25, LP35 Applications	
DODGE FULL SIZE PICKUP		
03-12	2500, 3500 2WD, 4WD Pickup	61901

Note:

1) Must remove factory overload contact spring or use 9703

ACCESSORIES



HELLWIG AIR™

- Better handling and control under heavily loaded conditions
- Maximize safe load carrying capacity, stability and ride quality
- Superior ride quality of this unit softens typical loaded ride conditions by transferring load from the vehicles leaf spring to the Hellwig Air Spring
- Simple installation for years of heavy duty control
- Each kit is designed to maximize safe load carrying capacity
- Longer stroke (less pressure for softer ride)
- Complete with double convoluted heavy duty air springs
- Lifetime warranty on Hellwig bracketery

HELLWIG AIR SUSPENSION

YEAR	APPLICATION	PART #
CHEVROLET/GMC FULL SIZE PICKUP & SUV		
01-06	C2500 LD 2WD,4WD P/U	6012
01-10	2500 HD 2WD,4WD P/U	6006
01-10	3500 HD 2WD,4WD P/U	6006
07-11	1500 Avalanche, Tahoe, Suburban, Yukon, Escalade	
	Powerlift Rear Air Suspension (Replaces Rear Coil Springs)	6097
	Powerlift Rear Air Suspension (w/o compressor,lv valve, & tank)	6091
FORD FULL SIZE PICKUP & SUV		
99-04	F250/F350 Super Duty 2WD Single Rear Wheel	6107 (2)
99-04	F250/F350 Super Duty 4WD Single Rear Wheel	6106 (2)
05-07	F250/F350 Super Duty 2WD Single Rear Wheel	6107 (2)
05-07	F250/F350 Super Duty 4WD Single Rear Wheel	6106 (2)
05-07	F250/F350 Super Duty 2WD Single Rear Wheel	6107 (2)
	w/ Factory Contact Overload	
05-07	F250/F350 Super Duty 4WD Single Rear Wheel	6106 (2)
	w/ Factory Contact Overload	
08-10	F250/F350 Super Duty 2WD Single Rear Wheel	6107 (2)
08-10	F250/F350 Super Duty 4WD Single Rear Wheel	6106 (2)
11-12	F250, 350 2wd single wheel	6111
11-12	F250 4wd single	6108
11-12	F350 4wd single	6113
DODGE FULL SIZE PICKUP		
03-11	2500, 3500 2wd & 4wd Pickup	6216
09-12	1500 2WD & 4WD (with coil springs)	
	Powerlift rear air suspension (replaces rear coil springs-complete kit)	6299
	Powerlift rear air suspension (replaces rear coil springs- w/o compressor etc)	6298

Note: (2) Can also use 6400 if not equipped with fifth wheel hitch

SEE HELLWIG MASTER CATALOG FOR LIFTED APPLICATIONS.

ACCESSORIES