

**HANDS FREE BLUETOOTH KIT**



- Background noise reduction
- Register up to three mobile phones
- Voice recognition (up to 150 names)
- Hands-free conversations with echo cancellation
- Wireless radio connection with your mobile phone
- Automatic muting of the car stereo & connection to your vehicle's speakers



**#CK3000**

**SCREENLESS HANDS FREE BLUETOOTH SYSTEM**



- Call pick up, hang up, dual calls
- Automatic phonebook synchronisation
- Voice menu to access functions
- Speech synthesis of the names in phonebook, contact management
- Training-free multi-speaker voice recognition



**#MKi9000**

**HANDS FREE BLUETOOTH KIT**



- Call Display
- Mutes the in-car radio
- Voice recognition • Volume control
- Pick-up and hang-up via voice command
- The names of your callers will appear on the screen
- Your phone book is accessible from the control screen



**#CK3100**

**BLUETOOTH SYSTEM**



All the features of the Mki9000 plus:

- OLED screen
- Wireless remote control



**#MKi9100**



**NEW MINIKIT**

**THE PARROT MINIKIT BLUETOOTH HANDS FREE CHARGING HOLDER FOR SMARTPHONES**

- VOICE RECOGNITION AND SPEECH SYNTHESIS
- ATTACHED TO THE WINDSHIELD OR DASHBOARD
- RECHARGE YOUR PHONE VIA A USB SOCKET PORT
- SYNCHRONIZES ITS PHONEBOOK W/YOUR CELL'S PHONEBOOK

The Parrot MINIKIT Smart is a Bluetooth hands-free kit featuring a Smartphone holder. It can be attached to the windshield or dashboard, enabling you to access the navigation and cell phone features while keeping your hands on the wheel at all times. You can use the MINIKIT Smart to recharge your phone via a USB socket port. Its numerous metal components and chrome finishes combine robustness and elegance. The Parrot MINIKIT Smart can easily switch from portrait to landscape mode to suit any configuration. Using a Smartphone's hands-free and navigation features in your car is now as easy as ever.

**#MINIKIT-SMART**



**NEW MINIKIT+**

**THE PARROT MINIKIT+ YOUR CALLS ARE TRULY HANDS-FREE**

- CONNECT SIMULTANEOUSLY TWO PHONES (MULTIPOINT)
- USE VOICE RECOGNITION TO CALL A CONTACT • ACCEPT OR REJECT CALLS BY VOICE
- AUTO SWITCH ON WHEN YOU ENTER CAR • STORE UP TO 20,000 CONTACTS IN THE KIT MEMORY • UP TO 6 MONTHS OF STANDBY WITH ULTRA LOW POWER MODE

It comes with an elastic strap which is easily reversible whether you have your sun visor down or up, ingenious and practical, enabling you to access the navigation and cell phone features while keeping your hands on the wheel at all times. Thanks to the Bluetooth A2DP audio profile, you can listen to navigation instructions from your smartphone or your music directly from the Parrot MINIKIT+. You may simultaneously connect two Bluetooth telephones and receive incoming calls on either one easily. Your calls are truly hands-free.

**#MINIKIT PLUS**

**BLUETOOTH KIT SYSTEM**



All the features of the MKi9000 plus:

- 2.4" high-resolution TFT colour screen
- Wireless remote control



**#MKi9200**



Parrot

**ELECTRONICS**

# INSTALLATION KITS (PART # FITS THE FOLLOWING APPLICATIONS:)

## #CDJTH2AMK

### CHRYSLER:

- \*2008-2011 Chrysler 300
- \*2008-2011 Chrysler Aspen
- \*2007-2008 Chrysler Sebring
- \*2008-2011 Chrysler Town and Country

### DODGE:

- \*2007-2011 Dodge Avenger
- \*2008-2011 Dodge Caravan/Grand Caravan

- \*2008-2011 Dodge Dakota
- \*2008-2011 Dodge Durango
- \*2008-2011 Dodge Journey
- \*2007-2011 Dodge Nitro
- \*2009-2011 Dodge Ram 1500-2500-3500

### JEEP:

- \*2009-2011 Jeep Commander
- \*2008-2011 Jeep Grand Cherokee

- \*2007-2011 Jeep Wrangler

### VOLKSWAGEN:

- \*2009-2011 Volkswagen Routan

## #GMTH3AMK

### BUICK:

- \*2007-2011 Buick Enclave
- \*2006-2011 Buick Lucerne

### CADILLAC:

- \*2007-2011 Cadillac Escalade

### CHEVROLET:

- \*2007-2011 Chevrolet 1500 New Body
- \*2007-2011 Chevrolet 2500HD New Body

- \*2007-2011 Chevrolet 3500HD New Body
- \*2007-2011 Chevrolet Avalanche
- \*2007-2009 Chevrolet Equinox
- \*2009-2011 Chevrolet Express Van
- \*2006-2011 Chevrolet Impala
- \*2006-2011 Chevrolet Monte Carlo
- \*2007-2011 Chevrolet Silverado New Body
- \*2007-2011 Chevrolet Suburban

- \*2007-2011 Chevrolet Tahoe
- \*2009-2011 Chevrolet Traverse LS and LT1

### GMC:

- \*2007-2011 GMC Acadia
- \*2007-2011 GMC Sierra New Body
- \*2007-2011 GMC Yukon, Yukon XL, Denali

## #NISTH2AMK

### INFINITI:

- \*2007-2011 Infiniti G35 (New Body Style)
- \*2007-2011 Infiniti G37

### NISSAN:

- \*2007-2011 Nissan Altima
- \*2009-2011 Nissan Cube
- \*2008-2011 Nissan Frontier
- \*2007-2011 Nissan Maxima

- \*2009-2011 Nissan Murano
- \*2008-2011 Nissan Pathfinder
- \*2008-2011 Nissan Rogue
- \*2007-2011 Nissan Sentra
- \*2008-2011 Nissan Titan
- \*2007-2011 Nissan Versa (Includes 2007 Versa with Rockford Subwoofer)
- \*2008 Nissan Xterra

## #FDTHP2AMK

### FORD (NON-AMP):

- \*2004-2011 Ford Crown Victoria
- \*2005-2011 Ford Econoline
- \*2007-2010 Ford Edge
- \*2005-2011 Ford Escape
- \*2004-2011 Ford Expedition (No mute button on face)
- \*2004-2011 Ford Explorer
- \*2004-2011 Ford F-150
- \*2005-2011 Ford F-250

- \*2005-2011 Ford F-350
- \*2005-2011 Ford F-450
- \*2005-2011 Ford F-550
- \*2009-2011 Ford Flex
- \*2005-2011 Ford Focus
- \*2005-2008 Ford 500
- \*2004-2011 Ford Freestar
- \*2005-2011 Ford Freestyle
- \*2004-2011 Ford F-Series

- \*2007-2011 Ford Fusion (No Vol button on Steering Wheel)
- \*2005-2011 Ford Mustang
- \*2008-2011 Ford Taurus
- \*2008-2011 Ford Taurus X
- FORD (NAV OR MUTE BUTTON ON RADIO):**
- \*2003-2011 Ford Crown Victoria
- \*2005-2011 Ford Escape
- \*2004-2011 Ford Expedition
- \*2004-2011 Ford Explorer

- \*2004-2011 Ford F-150
- \*2005-2011 Ford F-250
- \*2005-2011 Ford F-350
- \*2005-2011 Ford F-450
- \*2005-2011 Ford F-550
- \*2009-2011 Ford Flex
- \*2007-2011 Ford Fusion
- \*2005-2011 Ford Mustang
- \*2004-2011 Ford Ranger

## #TOYTH1AMK

### TOYOTA:

- \*1984-2011 Toyota 4 Runner
- \*1995-2011 Toyota Avalon
- \*1987-2011 Toyota Camry
- \*1986-2007 Toyota Celica
- \*1988-2011 Corolla
- \*1987-1988 Toyota Corolla FX16
- \*1988-1992 Toyota Corolla SR5
- \*1989-1992 Toyota Cressida

- \*2000-2003 Toyota Echo
- \*2006-2011 Toyota FJ Cruiser (FJammer System)
- \*2001-2011 Toyota Highlander
- \*1991-1998 Toyota Landcruiser
- \*2001-2002 Toyota Landcruiser
- \*2005-2011 Toyota Matrix
- \*1987-1995 Toyota MR2
- \*2001-2003 Toyota MR2 Spyder

- \*1992-1999 Toyota Paseo
- \*1986-1995 Toyota Pickup
- \*1991-1997 Toyota Previa
- \*2001-2011 Toyota Prius
- \*1996-2011 Toyota RAV4
- \*2001-2011 Toyota Sequoia
- \*1998-2011 Toyota Sienna
- \*1998-2011 Toyota Solara
- \*1986-1998 Toyota Supra

- \*1993-1998 Toyota T100
- \*1995-2011 Toyota Tacoma
- \*1987-1998 Toyota Tercel
- \*2000-2011 Toyota Tundra
- \*1987-1990 Toyota Van
- \*2009-2011 Toyota Venza
- \*2007-2011 Toyota Yaris