

PRESTIGE
DISTINGUISHED STYLING



www.PrestigeFenderFlares.com

FENDER FLARES

*shown image is a set of RX314S on a 2012 Ford F250

NO DRILLING into the vehicle is required

PRESTIGE fender flares are manufactured from 100% ABS plastic which is the OE approved material offering optimal performance and superior durability. No shortcuts, no compromises, and no sacrifices are how Prestige has become known for outstanding product quality and competitive value and our Limited Lifetime Warranty validates our commitment to superior quality with long life expectancy.



*shown image is a set of RX106T on a 2008 Chevy Silverado

Available in THREE styles...



STREET style | SX203T



RIVET style | RX203T



EXTRA WIDE style | EX203T

Available in TWO finishes



STANDARD finish



TEXTURE finish



CUTTING-EDGE Fender Flares

- OE approved ABS plastic
- Covers rust and fender blemishes
- Available in 3 styles
- Standard and Texture finishes
- Mounting hardware included
- Covers rust and fender blemishes
- Embossed part numbers
- Design for perfect fitment
- All models are paintable
- UV resistant from color fading
- Limited Lifetime Warranty

SX

RX

EX



SX314S on a
2012 Ford F-250



RX205T on a
2010 Dodge Ram 3500



EX103T on a
2006 GMC Sierra 1500



RX314S on a
2012 Ford F-250



SX313T on a
2009 Ford F-250



SX204T on a
2011 Dodge Ram 1500



RX106T on a
2008 Chevy Silverado



SX103T on a
2006 GMC Sierra 1500

prestigefenderflares.com • ctpdistributorsinc.com

Grande Prairie 1-800-803-7785

Edmonton 1-888-422-9329

Calgary 1-877-237-7660

Port Kells, Surrey 1-800-663-5356

ACCESSORIES



CHEVROLET				H x T	S	T	H x T	S	T	H x T	S	T
Blazer	1992-1994	FullSize Only *1	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	TBA	TBA	4 1/2" x 2"	EX101S	EX101T
C/K 1500	1988-1999	Excludes StepSide *1 *4	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	TBA	TBA	4 1/2" x 2"	EX101S	EX101T
C/K 2500	1989-2000	Excludes StepSide *1	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	TBA	TBA	4 1/2" x 2"	EX101S	EX101T
C/K 3500	1989-2000	Excludes Dually *1 *3	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	TBA	TBA	4 1/2" x 2"	EX101S	EX101T
Silverado 1500/HD	1999-2002	Excludes StepSide *4	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
caution Silverado 1500/HD	2003-2007	Excludes StepSide	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
Silverado 1500	2007-2011	*4	4 pc.	5" x 1"	SX106S	SX106T	5" x 2"	RX106S	RX106T	5" x 2"	TBA	TBA
Silverado 2500/HD	2001-2002		4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103S
caution Silverado 2500/HD	2003-2007	*4	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103S
Silverado 2500/HD	2007-2011	*4	4 pc.	5" x 1"	SX106S	SX106T	5" x 2"	RX106S	RX106T	5" x 2"	TBA	TBA
Silverado 3500/HD	2001-2002	Excludes Dually *3	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
caution Silverado 3500/HD	2003-2007	Excludes Dually *3 *4	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
Silverado 3500/HD	2007-2011	*4	4 pc.	5" x 1"	SX106S	SX106T	5" x 2"	RX106S	RX106T	5" x 2"	TBA	TBA
Suburban	1992-1999	*1	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	TBA	TBA	4 1/2" x 2"	EX101S	EX101T
Tahoe	1995-2000	2-Doors Only *1	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	TBA	TBA	4 1/2" x 2"	EX101S	EX101T
DODGE				H x T	S	T	H x T	S	T	H x T	S	T
Ram 1500	1994-2001	*1	4 pc.	4" x 1 3/4"	SX202S	SX202T	4 1/2" x 2 3/4"	RX202S	RX202T	-	-	-
Ram 1500	2002-2005	*2	4 pc.	4" x 1 1/4"	SX203S	SX203T	4 1/4" x 2 1/4"	RX203S	RX203T	4 1/4" x 2 1/4"	EX203S	EX203T
Ram 1500	2006-2008	*2	4 pc.	4" x 1 1/4"	SX203S	SX203T	4 1/4" x 2 1/4"	RX203S	RX203T	4 1/4" x 2 1/4"	EX203S	EX203T
Ram 1500	2009-2011		4 pc.	4 1/4" x 1"	SX204S	SX204T	4 1/4" x 2"	TBA	TBA	4 1/4" x 2"	TBA	TBA
Ram 2500	1994-2002	*1	4 pc.	4" x 1 3/8"	SX202S	SX202T	4 1/2" x 2 3/4"	RX202S	RX202T	-	-	-
Ram 2500	2003-2005	*2	4 pc.	4" x 1 1/4"	SX203S	SX203T	4 1/4" x 2 1/4"	RX203S	RX203T	4 1/4" x 2 1/4"	EX203S	EX203T
Ram 2500	2006-2009	*2	4 pc.	4" x 1 1/4"	SX203S	SX203T	4 1/4" x 2 1/4"	RX203S	RX203T	4 1/4" x 2 1/4"	EX203S	EX203T
Ram 2500	2010-2011		4 pc.	4 1/4" x 1"	SX205S	SX205T	4 1/4" x 2"	RX205S	RX205T	4 1/4" x 2"	TBA	TBA
Ram 3500	1994-2002	Excludes Dually *1 *3	4 pc.	4" x 1 3/8"	SX202S	SX202T	4 1/2" x 2 3/4"	RX202S	RX202T	-	-	-
Ram 3500	2003-2005	Excludes Dually *2 *3	4 pc.	4" x 1 1/4"	SX203S	SX203T	4 1/4" x 2 1/4"	RX203S	RX203T	4 1/4" x 2 1/4"	EX203S	EX203T
Ram 3500	2006-2009	Excludes Dually *2 *3	4 pc.	4" x 1 1/4"	SX203S	SX203T	4 1/4" x 2 1/4"	RX203S	RX203T	4 1/4" x 2 1/4"	EX203S	EX203T
Ram 3500	2010-2011	Excludes Dually *3	4 pc.	4 1/4" x 1"	SX205S	SX205T	4 1/4" x 2"	RX205S	RX205T	4 1/4" x 2"	TBA	TBA
FORD				H x T	S	T	H x T	S	T	H x T	S	T
caution F-150	1997-2004	Excludes StepSide *4	4 pc.	4 1/2" x 1"	SX303S	SX303T	5" x 2"	TBA	RX303T	-	-	-
F-150	2004-2008	Includes StepSide for SX style Only *4	4 pc.	3" x 1 1/2"	TBA	SX310T	6 1/2" x 2"	TBA	RX310T	-	TBA	TBA
F-150	2009-2011		4 pc.	3" x 1 1/2"	TBA	SX310T	-	TBA	TBA	-	TBA	TBA
F-250	1998		4 pc.	4 1/2" x 1"	SX303S	SX303T	5" x 2"	TBA	RX303T	-	-	-
F-250	1999-2005		4 pc.	3 1/4" x 1"	SX311S	SX311T	5 1/2" x 2"	RX311S	RX311T	5 1/2" x 2"	EX311S	EX311T
F-250	2006-2007		4 pc.	3 1/4" x 1"	SX311S	SX311T	5 1/2" x 2"	RX311S	RX311T	5 1/2" x 2"	EX311S	EX311T
F-250	2008-2010		4 pc.	3 1/4" x 1"	SX313S	SX313T	5 1/2" x 2"	RX313S	RX313T	5 1/2" x 2"	TBA	TBA
F-250	2011 +		4 pc.	3 1/4" x 1"	SX314S	SX314T	6 3/4" x 2 1/4"	RX314S	RX314T	6 3/4" x 2 1/4"	EX314S	EX314T
F-350	1999-2007	Excludes Dually *3	4 pc.	3 1/4" x 1"	SX311S	SX311T	5 1/2" x 2"	RX311S	RX311T	5 1/2" x 2"	EX311S	EX311T
F-350	2008-2010	Excludes Dually *3	4 pc.	3 1/4" x 1"	SX313S	SX313T	5 1/2" x 2"	RX313S	RX313T	5 1/2" x 2"	TBA	TBA
F-350	2011 +	Excludes Dually *3	4 pc.	3 1/4" x 1"	SX314S	SX314T	6 3/4" x 2 1/4"	RX314S	RX314T	6 3/4" x 2 1/4"	EX314S	EX314T
GMC				H x T	S	T	H x T	S	T	H x T	S	T
Sierra 1500	1988-1999	Excludes StepSide *1 *4	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	RX101S	TBA	4 1/2" x 2"	EX101S	EX101T
caution Sierra 1500/HD	1999-2007	Excludes StepSide *4	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
Sierra 1500	2007-2011	*4		-	TBA	TBA	-	TBA	TBA	-	TBA	TBA
Sierra 2500	1989-2000	Excludes StepSide *1 *4	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	RX101S	TBA	4 1/2" x 2"	EX101S	EX101T
caution Sierra 2500/HD	2000-2007	*4	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
Sierra 2500/HD	2007-2010	Excludes Dually *3 *4	4 pc.	-	TBA	TBA	-	TBA	TBA	-	TBA	TBA
Sierra 2500/HD	2011 +	Excludes Dually *3	4 pc.	-	TBA	TBA	-	TBA	TBA	-	TBA	TBA
Sierra 3500	1989-2000	Excludes Dually *1 *3	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	RX101S	TBA	4 1/2" x 2"	EX101S	EX101T
caution Sierra 3500/HD	2003-2007	Excludes Dually *3 *4	4 pc.	4" x 1"	SX103S	SX103T	4" x 2"	RX103S	RX103T	4" x 2"	EX103S	EX103T
Sierra 3500/HD	2007-2010	Excludes Dually *3 *4	4 pc.	-	TBA	TBA	-	TBA	TBA	-	TBA	TBA
Sierra 3500/HD	2011 +	Excludes Dually *3	4 pc.	-	TBA	TBA	-	TBA	TBA	-	TBA	TBA
Yukon	1992-1999	2 Doors Only *1	4 pc.	4" x 1"	TBA	SX101T	4 1/2" x 2"	RX101S	TBA	4 1/2" x 2"	EX101S	EX101T
TOYOTA				H x T	S	T	H x T	S	T	H x T	S	T
Tundra	2007-2011		4 pc.	-	TBA	TBA	-	TBA	TBA	-	TBA	TBA

H x T = Height x Tire Coverage (The height and tire coverage is measured from the top dead center of the front fender well)

*1. If bodyline moldings exists, then it will need to be removed or trimmed.

*2. Vehicle with an emblem may require relocation of the emblem.

*3. Front flares are available for Dually models.

*4. Be aware of overlapping years. e.g. 2007 Chevrolet Silverado Classic looks like a 2006 model.

caution See note *4 for overlapping years.

v.20120101

ACCESSORIES