



Updated  
08.08.11

SuperBracket Custom Brackets and SuperRail Brackets are not interchangeable - SuperBrackets use standard Super 5th base rails - SuperRails are unique, totally removable base rails.

## MOUNTING KIT APPLICATION CHART

	Universal Mounting Kits	SuperBracket Mounting Kits	SuperRail Mounting Kits
<b>1200 &amp; 0800 Super 5<sup>th</sup> Hitches</b>			
<b>16K Weight Rating</b> Part #1200			
<b>20.5K Weight Rating</b> Part #0800			
			
<b>Chevrolet</b>	PullRite #	PullRite #	PullRite #
1999 - 2000 2500 & 3500 Ext/Crew Cab Long Bed	0820		
2001 - 2010 2500 & 3500 HD	0820	0826	0843
1999 - 2011 1500 (not 5'8" bed)	0820		
2011 2500 & 3500 HD (spline bolts and flange nuts required; not supplied in kit prior to 6/11)	0820	0830	0847
<b>Dodge</b>			
1995 - 2002 (except '02-'04 1/2 Ton)	0820	0824	0842
2002 - 2008 1500 (requires drilling 8 holes. Spline bolts and flange nuts required; not supplied in kit prior to 6/11)	0820		
2003 - 2010 2500 & 3500 (NO DRILL) (except 2WD, 3500)		0827	0844
2011 - 2500 & 3500 (NO DRILL) (except 2WD, 3500 w/ overload springs)		0831	0848
2003 - 2010 3500 2WD (NO DRILL) *price check required		*0828	
<b>Ford</b>			
1997 - 2003 F150	0820		
1999 - 2011 F250 & F350	0820	0822	0841

**NEW!**

### Industry Standard Super 5<sup>th</sup>

Industry Standard Mounting Brackets and Base Rails give you the best quality and value from your Super 5<sup>th</sup>. The 2100 can be ordered with our Industry Standard Universal Mounting Bracket kit or mounts to most "other guy's" base rails already installed in your bed.



**18K Weight Rating**  
Part #2100

**16K Weight Rating**  
Part #1900



Universal Kit



PullRite #

<b>Chevy</b>	2003-2011 2500 & 3500 HD	2720
<b>Dodge</b>	2003 - 2011 2500 & 3500 (does not fit 3500 w/ overload springs)	2720
	2003 - 2011 2500 & 3500 (does not include 2WD, 3500 w/ overload springs)	2722
<b>Ford</b>	1999 - 2011 F250 & F350	2720

ACCESSORIES



Updated  
08.08.11

For towing the "big rigs," you will find our 25.5K rated hitches superior for the task! The compact pyramid base of the 0503 is designed for maximum strength and pleasing appearance, while the 0515 is designed for custom flat bed vehicles with extra high ground clearance.

**MOUNTING KIT APPLICATION CHART**

**Universal Mounting Kits**

**SuperBracket Mounting Kits**

Kit includes "L" Brackets, Base Rails & Hardware

Kit includes Custom Mounting Brackets, Base Rails, & Hardware

Long Bed & Short Bed

Long Bed & Short Bed

**0503 & 0515 Super 5<sup>th</sup> Hitches**

Universal Kit

SuperBracket Kit

**25.5K Weight Rating**  
(height adjustable model #0504 available)  
Part #0503



**25.5K Weight Rating**  
(height adjustable model #0516 available)  
Part #0515



**Chevrolet**

PullRite #

PullRite #

1999 - 2000 2500 & 3500 Ext/Crew Cab Long Bed

0520

0517

2001 - 2010 2500 & 3500 HD

0520

0527

2011 2500 & 3500 HD

0520

0533

**Dodge**

1995 - 2002 (except '02 1/2 Ton)

0520

0524

2003 - 2010 2500 & 3500 (NO DRILL) \*price check required

\*0525

**Ford**

1999 - 2011 F250 & F350

0520

0522

Height adjustable mounting kit applications available. Call for more information.

**NEW!**

**Industry Standard SuperGlide**

Universal Kit

The new Industry Standard SuperGlide can be ordered with our Industry Standard Universal Mounting Bracket kit, or if you have "the other guy's" base rails mounted in your bed, replace the problems and hassles of a manual slider with an American made, automatic SuperGlide...and JUST DRIVE!

**18K Weight Rating**  
Part #2900

**15K Weight Rating**  
Part #2700



PullRite #

**Chevy** 2003-2011 2500 & 3500 HD

2720

**Dodge** 2003 - 2011 2500 & 3500  
(does not fit 3500 w/ overload springs)

2720

**Dodge** 2003 - 2011 2500 & 3500  
(does not include 2WD, 3500 w/ overload springs)

2722

**Ford** 1999 - 2011 F250 & F350

2720

pullrite.com • ctpdistributorsinc.com

Grande Prairie 1-800-803-7785

Edmonton 1-888-422-9329

Calgary 1-877-237-7660

Port Kells, Surrey 1-800-663-5356



# SuperGlide - Short Bed Fifth Wheel Hitches

Call for application info when king pin is located behind front edge of trailer.

The 4100 & 4400 SuperGlide hitches have the option of using either Universal Mounting Kits with fixed base rails or SuperRail Kits, with custom designed mounting brackets and totally removable SuperRails and Mounting Posts.

The 3100 & 3600 SuperGlide hitch mounting kits all feature custom-designed mounting brackets and are totally removable.

The super short (less than 6') bed trucks are usually not recommended for fifth wheel towing, however, with some trailer limitations (e.g. king pin location & trailer width) the 3100 SuperGlide, may make towing possible. In cases where there will be less than 3" clearance between the cab and trailer, including a 90 degree turn, the 3100 is not recommended. SuperRail Mounting Brackets for the 3100 SuperGlide are only available for the trucks listed, there are no mounting brackets made to fit any other application. For specific vehicle/trailer combinations, call for additional information.

3100 SuperGlide	4100 & 4400 SuperGlide		3600 SuperGlide
Requires Mounting Kit Below	Requires either a Universal OR SuperRail Mounting Kit		Requires Mounting Kit Below
PullRite #	PullRite #	PullRite #	PullRite #
3100	4100	4400	3600
<b>12K Weight Rating</b>	<b>16K Weight Rating</b>	<b>18K Weight Rating</b>	<b>24K Weight Rating</b>
SuperRail Kits	Universal Rail Kits	SuperRail Kits	SuperRail Kits
Includes removable SuperRails & Posts, Mounting Brackets and Hardware. The 3100 features a totally removable baserail design.	Universal Rail Kit includes "bolt to the bed" Base Rails, Universal "L" Brackets and Hardware. Fits both 4100 and 4400	Includes totally removable SuperRails & Posts, Mounting Brackets & Hardware. Fits both 4100 and 4400	Includes totally removable Mounting Posts, Brackets and Hardware. The 3500 requires no baserails.
PullRite #	PullRite #	PullRite #	PullRite #
<b>Chevrolet</b>			
1999-2010 2500 & 3500		3340	3345
1999-2007 1500 (6-1/2' bed, except 2007 new body style)		3340	3345
2007-2011 1500 (6-1/2' bed, new body style)			4423
2004-2007 1500 (5'8" Bed, except 2007 current body style. Added limitations on trailers 98" or wider)	3114		
2007-2011 1500 (5'8" bed, current body style only)	3117		
2011 2500 & 3500		4428	3521
<b>Dodge</b>	SuperRail Kits	Universal Rail Kits	SuperRail Kits
1995-2002 (except '02 1500)		3340	3346
2003-2011 2500 & 3500, 2002-2008 1500, 2006-2011 Mega Cab (NO DRILL) (added limitations on trailers 96" or wider)			3349
2009-2011 1500 (5'7" & 6-1/2' bed, added limitations 96" or wider trailers)	3120		
<b>Ford</b>	SuperRail Kits	Universal Rail Kits	SuperRail Kits
1997-2003 F-150 (not SuperCrew)		3340	3342
1999-2010 F250 & F350 (not for 2011 Diesel...see below)		3340	3343
1999-2011 F250 & F350 (for gas or Diesel w/ #3600 SG exception below)		3340	4426
2011 F250 & F350 Diesel (for #3600 SG, 6-1/2" bed)			3520
2001-2003 SuperCrew F-150 (5'6" bed)	3111		
2004-2011 F-150 (6-1/2' bed)			3361
2004-2008 SuperCrew F-150 (5'6" bed. Added limitations on trailers over 90" wide)	3113		
2009-2011 F-150 (5'7" bed, added limitations on 96" or wider trailers)	3119		
<b>Nissan</b>	SuperRail Kits	Universal Rail Kits	SuperRail Kits
2004-2011 Titan Short Beds (Crew Cab limitations on trailers over 90" wide, King Cab may be used up to 102" wide - call for more information)	3115		
<b>Toyota</b>	SuperRail Kits	Universal Rail Kits	SuperRail Kits
2001-2006 Tundra (Standard Extra Cab)	3112		
2007-2011 Tundra (Double Cab Only, 6-1/2' bed, Universal Rails with Custom Mounting Brackets)		4421	
2007-2011 Tundra (Crew Max and 5'8" bed Only)	3118		