

HUSKYLINERS®

FLOOR · CARGO · TRUNK LINERS

All part numbers are five digits long with the last digit being the color code (i.e. 24101)
Add last digit color code to part numbers: 1=Black, 2=Grey, 3=Tan

| MAKE | YEAR | MODEL | FRONT LINER | HUMP LINER | SECOND SEAT LINER | CARGO LINER | |
|------------------|---|---|---|------------|-------------------|-------------|-------------|
| CHEVY/GMC | 07-10 | Acadia (2nd row buckets/bhnd 3rd seat CL 2nd row bench/behind 2nd seat cargo liner) | 3101_ | | 6102_ 6103_ | 2103_ 2101_ | |
| | | Avalanche | 3141 | 8244 | 6243 | | |
| | 04-09 | Colorado/Canyon Reg/Ext Cab (Black/Grey Only) | 3250 | 8249 | 6250 | | |
| | 04-09 | Colorado/Canyon Crew Cab (Black/Grey Only) | 3251 | | 6251 | | |
| | 02-08 | Envoy/Envoy Denali/Trailblazer | 3200 | | 6202 | 2200 | |
| | 06-09 | Equinox w/o adjustable cargo tray | 3108 | | 6108 | 2107 | |
| | 07-09 | Suburban/YukonXL&Denali (w/3rd seat) | 3141 | 8244 | 6243 | 2143 | |
| | 07-09 | Suburban/YukonXL&Denali (w/o 3rd seat) | 3141 | 8244 | 6243 | 2144 | |
| | 07-09 | Tahoe/Yukon/Yukon Denali (w/3rd seat opt) | 3141 | 8244 | 6142 | 2141 | |
| | 07-09 | Tahoe/Yukon/Yukon Denali (w/o 3rd seat opt) | 3141 | 8244 | 6142 | 2142 | |
| | 08-09 | Tahoe Hybrid | 3141 | | 6153 | 2153 | |
| | 2009 | Trailblazer/Envoy | 3201 | | 6202 | 2200 | |
| | 2009 | Traverse (2nd row buckets/bhnd 3rd seat CL 2nd row bench/behind 2nd seat cargo liner) | 3101_ 3101 | | 6102_ 6103_ | 2106_ 2104_ | |
| | 07-09 | Trk Reg Cab Silverado/Sierra & HD Series | 3135 | 8222 | | | |
| | 07-09 | Trk Ext Cab Silverado/Sierra & HD Series | 3141 | 8223 | 6137 | | |
| | 07-09 | Trk Crew Cab Silverado/Sierra/HD Series | 3141 | 8223 | 6152 | | |
| | CHR/DODGE | 05-10 | Dakota Quad Cab (Black/Grey Only) | 3035 | | 6036 | |
| | | 06-09 | Durango/Aspen (CL w/o 3rd seat/folded down) | 3040 | | 6040 | 2041_ |
| | | 09-10 | Ram Crew Cab 1500 Series CHL-A/T | 3082 | | 6082 | |
| | | 03-09 | Ram 2500/3500 & 02-08 1500 Series CHL-A/T | 3080 | 8280 | 6080 | |
| 06-09 | | Ram Mega Cab (29941 fits over 2nd seat) | 3080 | | 6085 | 29941 | |
| FORD/MERC/ MAZDA | | 2008 | Escape/Tribute/Mariner | 3317 | | 6317 | 2316 |
| | | 2008 | Escape/Mariner Hybrid | 3317 | | 6317 | 2314 |
| | | 07-10 | Expedition (CL fits to back of 2nd seat) 3rd seat liner/crg liner behind 3rd seat | 3353_ | | 6353_ 7353_ | 2357_ 2355_ |
| | | 07-10 | Expedition EL (CL to back of 2nd seat) 3rd seat liner/crg liner behind 3rd seat | 3353_ | | 6353_ 7353_ | 2354_ 2353_ |
| | | 06-10 | Explorer/Mountaineer | 3375 | | 6377 | 2375 |
| | 05-09 | Ranger/Mazda Reg/Super Cab 4dr | 3374 | | 6373 | | |
| | 05-08 | Ranger/Mazda Reg/Super Cab 2dr | 3374 | | 6372 | | |
| | 2008 | Taurus X (Cargo Liner-behind 3rd seat) (behind 2nd seat over folded flat 3rd seat) | 3312 | | 6311 | 2312_ 2310 | |
| | 2009 | Trk FS F150 Super Crew | 3369 | | 6369 | | |
| | 2009 | Trk FS F150 Reg/Super Cab | 3369 | | | | |
| | 04-08 | Trk FS F150 Reg Cab | 3365 | 8366 | | | |
| | 04-08 | Trk FS F150 Super Cab | 3365 | 8365 | 6367 | | |
| | 04-08 | Trk FS F150 Super Crew | 3365 | 8365 | 6368 | | |
| | 08-10 | F250-450 Super Duty Reg Cab | 3368 | 8247 | | | |
| | 08-10 | F250-450 Super Duty Super Cab | 3368 | 8248 | 6388 | | |
| 08-10 | F250-450 Super Duty Crew Cab | 3385 | 8248 | 6382 | | | |
| JEEP | 06-10 | Commander | 3061 | | 6065 | 2065 | |
| | 05-10 | Grand Cherokee 4Dr | 3061 | | 6061 | 2061 | |
| | 08-09 | Liberty | 3025 | | 6025 | 2025 | |
| | 07-10 | Wrangler (6052-Black/Grey Only) | 3052 | | 6052 | 2052 | |
| | 07-10 | Wrangler Unlimited (6053/2053-Black/Grey) | 3052 | | 6053 | 2053 | |
| NISSAN | 04-10 | Armada (8265-Black/Grey Only) | 3661 | 8265 | 6660 | 2660 | |
| | 05-10 | Frontier King Cab P/U | 3626 | | 6626 | | |
| | 05-10 | Frontier Crew Cab P/U | 3636 | | 6627 | | |
| | 05-10 | Pathfinder | 3625 | | 6625 | 2625 | |
| | 04-09 | Titan Ext Cab Truck (8265/6661 Black/Grey) | 3661 | 8265 | 6661 | | |
| | 04-09 | Titan Crew Cab Truck (8265/6661 Black/Grey) | 3661 | 8265 | 6665 | | |
| | 05-09 | Xterra SUV (6628/2628 Black/Grey Only) | 3625 | | 6628 | 2628 | |
| TOYOTA | 03-08 | 4Runner w/o double stack cargo tray | 3575 | | 6575 | 2575 | |
| | 03-08 | 4Runner w/double stack cargo tray | 3575 | | 6575 | 2576 | |
| | 04-09 | 4Runner w/3rd seat | 3575 | | 6575 | 2571 | |
| | 07-09 | FJ Cruiser w/auto only (Black Only) | 35961 | | 65961 | 25951 | |
| | 08-09 | Sequoia (3rd seat liner-7557) | 3558 | | 6557 | 2557 | |
| | 09-10 | Tacoma Access Cab | 3549 | | 6546 | | |
| | 05-08 | Tacoma Reg/Acc Cab (2nd seat Cargo Liner) | 3549 | | 6548 | 29951 | |
| | 05-10 | Tacoma Double Cab Truck | 3549 | | 6549 | | |
| | 07-09 | Tundra CrewMax (Dbl Cab w/underseat strg) | 3558 | 8258 | 6559 | | |
| 07-09 | Tundra Reg/Dbl Cab w/o underseat strg box | 3558 | 8258 | 6558 | | | |

FRONT SEAT LINER



- OVER 20 YEARS OF PROVEN PROTECTION AT KEEPING DEBRIS AND SPILLS OFF YOUR VEHICLE'S CARPET.
- OUR CUSTOM FIT DESIGN PROVIDES YOUR VEHICLE WITH MAXIMUM COVERAGE AND MAXIMUM FLOOR PROTECTION.
- MADE FROM OUR HIGHLY DURABLE PATENTED MATERIALS. OUR LINERS WILL LAST THE LIFE OF YOUR VEHICLE WHILE PROTECTING AGAINST HARSH CHEMICALS LIKE OIL, GASOLINE AND BATTERY ACID.
- FEATURES "BPIN" STA-PUT-NIBB ON BACK TO HELP PREVENT SHIFTING.
- INSTALLS IN SECONDS AND IS EASY TO CLEAN.
- LIFETIME WARRANTY AGAINST CRACKING, BREAKING & MANUFACTURER DEFECTS.
- AVAILABLE IN BLACK, GREY AND TAN TO COMPLIMENT ALL INTERIORS.

BACK SEAT LINER



CARGO LINER



www.huskyliners.com • www.customtruckpartsinc.com

Grande Prairie 1-800-803-7785

Edmonton 1-888-422-9329

Calgary 1-877-237-7660

Port Kells, Surrey 1-800-663-5356

HUSKYLINERS®

weatherBEATER

FRONT SEAT LINER



CENTER HUMP LINER



BACK SEAT LINER



TRUNK LINER

- OVER 20 YEARS OF PROVEN PROTECTION AT KEEPING DEBRIS AND SPILLS OFF YOUR VEHICLE'S CARPET.
- OUR CUSTOM FIT DESIGN PROVIDES YOUR VEHICLE WITH MAXIMUM COVERAGE AND MAXIMUM FLOOR PROTECTION.
- MADE FROM OUR HIGHLY DURABLE PATENTED MATERIALS. OUR LINERS WILL LAST THE LIFE OF YOUR VEHICLE WHILE PROTECTING AGAINST HARMFUL CHEMICALS LIKE OIL, GASOLINE AND BATTERY ACID.
- FEATURES "BPIN" STA-PUT-NIBS ON BACK TO HELP PREVENT SHIFTING.
- INSTALLS IN SECONDS AND IS EASY TO CLEAN.
- LIFETIME WARRANTY AGAINST CRACKING, BREAKING & MANUFACTURER DEFECTS.
- AVAILABLE IN BLACK, GREY AND TAN TO COMPLIMENT ALL INTERIORS.

| YEAR | APPLICATION | Front/2nd Pt # | Trunk/Crg Pt # |
|---------|--|----------------|----------------|
| 2010 | Chevrolet Camaro (Front/2nd seat sold together) | 9812 | 42051 |
| 2005-09 | Chevrolet Cobalt 4-Door (Front/2nd seat sold together) | 9810 | 42011 |
| 2010 | Chevrolet Equinox (Front/2nd seat sold together) | 9813 | 2113 |
| 2008-10 | Chevrolet Malibu (Front/2nd seat sold together) | 9811 | 42001 |
| 2009 | Silverado/Sierra Crew Cab (Front/2nd seat sold together) | 9820 | |
| 2009 | Silverado/Sierra Ext Cab (Front/2nd seat sold together) | 9821 | |
| 2009 | Silverado/Sierra Crew/Ext Cab (Center Hump Liner) | 8228 | |
| 2008-09 | Dodge Challenger (Front/2nd seat together) | 9802 | |
| 2009-10 | Dodge Ram 1500 Series Crew Cab (Front/2nd seat together) | 9800 | |
| 2009-10 | Dodge Ram 1500 Series Crew Cab (Center Hump Liner) | 8370 | |
| 2009-10 | Dodge Ram 1500 Series Quad Cab (Front/2nd seat together) | 9801 | |
| 2009-10 | Dodge Ram 1500 Series Quad Cab (Center Hump Liner) | 8371 | |
| 2002-10 | Dodge Ram (Fronts Only) Reg/Quad Cab | 1801 * | |
| 2002-08 | Dodge Ram 1500 Series Quad Cab & 03-09 2500/3500 | 9803 | |
| 2009-10 | Ford Escape (Front/2nd seat sold together) | 9835 | 2322 |
| 2009-10 | Ford Escape Hybrid (Front/2nd seat sold together) | 9835 | 2323 |
| 2009-10 | Ford F-150 (Fronts Only) Reg/Super Cab/Super Crew | 1833 * | |
| 2009-10 | Ford F-150 Super Cab (Front/2nd seat sold together) | 9834 | |
| 2009-10 | Ford F-150 Super Crew (Front/2nd seat sold together) | 9833 | |
| 2009-10 | Ford F-150 Super Cab/Super Crew (Center Hump Liner) | 8342 | |
| 2009-10 | Ford F-150 (2nd Seat Only) Super Crew | 1933 * | |
| 2009 | Ford Flex CL behind 2nd seat (Front/2nd seat sold together) | 9832 | 23191 |
| 2009 | Ford Flex CL behind 3rd seat (Front/2nd seat sold together) | 9832 | 2312 |
| 2008-10 | Ford Focus 4-Door (Front/2nd seat sold together) | 9831 | 43001 |
| 2006-10 | Ford Fusion-Front Wheel Drive (Front/2nd seat together) | 9830 | 43011 |
| 2010 | Ford Fusion/Hybrid FWD (Front/2nd seat together) | 9836 | |
| 2010 | Ford Mustang (Front/2nd seat sold together) | 9837 | |
| 2010 | Ford Taurus (Front/2nd seat sold together) | 9870 | |
| 2008-09 | Honda Accord 4-Door (Front/2nd seat sold together) | 9840 | 44001 |
| 2006-09 | Honda Civic 4-Door (Front/2nd seat sold together) | 9841 | 44011 |
| 2010 | Honda Insight (Front/2nd seat sold together) | 9843 | 44031 |
| 2009-10 | Honda Pilot (Front/2nd seat sold together) | 9842 | 2436 |
| 2010 | Lexus RX 350 (Front/2nd seat sold together) | 9855 | 2589 |
| 2007-09 | Lincoln MKZ-Front Wheel Drive (Front/2nd seat sold together) | 9830 | |
| 2010 | Lincoln MKZ/Hybrid FWD (Front/2nd seat sold together) | 9836 | |
| 2006 | Lincoln Zephyr FWD (Front/2nd seat sold together) | 9836 | |
| 2006-09 | Mercury Milan-Front Wheel Drive (Front/2nd seat sold together) | 9830 | 43011 |
| 2010 | Mercury Milan/Hybrid FWD (Front/2nd seat together) | 9836 | |
| 2007-09 | Nissan Altima 4-Door (Front/2nd seat sold together) | 9860 | 44601 |
| 2009-10 | Pontiac Vibe FWD-w/auto, 2502-Grey/Tan (Front/2nd together) | 9853 | 2502 |
| 2007-09 | Saturn Aura (Front/2nd seat sold together) | 9811 | 42001 |
| 2007-10 | Toyota Camry (Front/2nd seat sold together) | 9851 | 44501 |
| 2009-10 | Toyota Corolla FWD-w/auto (Front/2nd seat sold together) | 9853 | |
| 2009-10 | Toyota Matrix FWD-w/auto, 2502-Grey/Tan (Front/2nd together) | 9853 | 2502 |
| 2004-09 | Toyota Prius (Front/2nd seat sold together) | 9852 | 4452 |
| 2010 | Toyota Prius (Front/2nd seat sold together) | 9856 | 44571 |
| 2009 | Toyota Venza (Front/2nd seat sold together) | 9854 | 2504 |

All part numbers are five digits long with the last digit being the color code (i.e. 98101)

Add last digit color code to part numbers: 1=Black, 2=Grey, 3=Tan; Trunk Liners only available in Black

* = Fronts Only, sold as a single set (No 2nd seats)

HUSKYLINERS®

HEAVY DUTY FLOOR MATS

All part numbers are five digits long with the last digit being the color code (i.e. 24101), Add last digit color code to part numbers: 1=Black, 2=Grey, 3=Tan; * = For vehicles in Need of Center Hump Protection

| MAKE | YEAR | MODEL | FRONT SEAT MAT | CENTER HUMP MAT | 2ND SEAT MAT |
|------------|----------|--|----------------|-----------------|--------------|
| CHEVY/GMC | 2007-09 | ACADIA/TRAVERSE | 5114 | N/A | 5201 |
| | 2007-09 | AVALANCHE | 5118 | N/A | 5202 |
| | 2005-09 | COBALT | 5111 | N/A | 5203 |
| | 2004-09 | COLORADO/CANYON | 5112 | 5300 * | 5202 |
| | 2005-09 | EQUINOX | 5111 | N/A | 5202 |
| | 2007-09 | HD SERIES | 5118 | N/A | 5202 |
| | 2005-09 | HHR | 5111 | N/A | 5202 |
| | 96-2010 | IMPALA | 5105 | N/A | 5202 |
| | 2008-10 | MALIBU | 5105 | N/A | 5202 |
| | 2007-09 | SILVERADO/SIERRA | 5118 | N/A | 5202 |
| | 2007-09 | SUBURBAN/YUKON/YUKON DENALI/ YUKON XL/YUKON XL DENALI | 5118 | N/A | 5202 |
| | 2007-09 | TAHOE | 5118 | N/A | 5202 |
| | 2002-09 | TRAILBLAZER/EXT & ENVOY/XL - THIRD SEAT FLOOR MAT | 5113 | N/A | 5202 5202 |
| | 2005-08 | UPLANDER - THIRD SEAT FLOOR MAT | 5114 | N/A | 5201 5202 |
| | CHRYSLER | 2007-09 | ASPEN | 5123 | N/A |
| DODGE | 2005-10 | DAKOTA QUAD CAB | 5112 | N/A | 5202 |
| | 2004-09 | DURANGO | 5123 | N/A | 5202 |
| | 2002-10 | RAM 1500/2500/3500 SERIES | 5122 | 5300 * | 5202 |
| | 2006-09 | RAM MEGA CAB - FULL SIZE | 5122 | N/A | 5202 |
| FORD | 2007-10 | EDGE | 5117 | N/A | 5202 |
| | 2001-08 | ESCAPE | 5105 | N/A | 5202 |
| | 2003-10 | EXPEDITION/EXPEDITION EL - THIRD SEAT FLOOR MAT | 5123 | 5300 * | 5201 5202 |
| | 2002-10 | EXPLORER | 5112 | 5300 * | 5202 |
| | 2007-09 | EXPLORER SPORT TRAC | 5112 | N/A | 5202 |
| | 2004-10 | F-150 | 5123 | 5300 * | 5201 |
| | 99-2007 | F250-550 SUPER DUTY | 5104 | 5300 * | 5201 |
| | 2008-10 | F250-450 SUPER DUTY | 5120 | 5300 * | 5201 |
| | 2006-10 | FUSION | 5117 | N/A | 5202 |
| | 2005-07 | MUSTANG | 5112 | N/A | N/A |
| | UP TO 09 | RANGER | 5107 | N/A | 5202 |
| HONDA | UP TO 07 | ACCORD & CIVIC 4DR/CIVIC Si | 5111 | N/A | 5202 |
| | 2007-09 | CR-V | 5105 | N/A | 5202 |
| | 2003-08 | PILOT | 5114 | 5300 * | 5201 |
| JEEP | 2005-09 | GRAND CHEROKEE | 5116 | N/A | 5202 |
| | 2002-07 | LIBERTY | 5108 | N/A | 5202 |
| | 2007-10 | WRANGLER | 5108 | N/A | (LINERS) |
| | 2007-10 | WRANGLER UNLIMITED | 5108 | N/A | 5202 |
| NISSAN | 2002-06 | ALTIMA | 5105 | N/A | 5202 |
| | 2004-10 | ARMADA - THIRD SEAT FLOOR MAT | 5123 | N/A | 5202 5202 |
| | 2005-10 | PATHFINDER | 5111 | N/A | 5202 |
| | UP TO 09 | SENTRA | 5105 | N/A | 5202 |
| | 2004-09 | TITAN TRUCK | 5123 | 5300 * | 5201 |
| | 2000-09 | XTERRA | 5111 | N/A | 5202 |
| TOYOTA | 2003-09 | 4RUNNER | 5111 | N/A | 5202 |
| | 2005-06 | CAMRY | 5117 | N/A | 5202 |
| | UP TO 08 | COROLLA | 5117 | 5300 * | 5202 |
| | 2005-08 | HIGHLANDER/HYBRID | 5117 | N/A | 5202 |
| | 2005-07 | LAND CRUISER | 5111 | N/A | 5202 |
| | 2003-08 | MATRIX | 5117 | N/A | 5202 |
| | 2006-08 | RAV4 | 5111 | N/A | 5202 |
| | 2005-07 | SEQUOIA - THIRD SEAT FLOOR MAT | 5111 | N/A | 5201 5202 |
| | 2008-10 | SEQUOIA | 5121 | N/A | 5202 |
| | UP TO 10 | SIENNA VAN - THIRD SEAT FLOOR MAT | 5114 | N/A | 5201 5201 |
| VOLKSWAGEN | UP TO 10 | TACOMA | 5111 | N/A | 5202 |
| | 2007-10 | TUNDRA REG/DBL/CREWMAX | 5121 | 5300 * | 5202 |
| | 98-2009 | BEETLE | 5111 | 5300 * | 5202 |
| 2004-09 | TOUAREG | 5111 | N/A | 5202 | |



- 3/8" HIGH RIDGES ARE UP TO 40% TALLER
- FEATURES EXTRA THICK DRIVER'S HEEL PAD FOR LONGER LIFE
- GUARANTEED NOT TO CRACK OR BREAK
- EASILY CLEANED
- FEATURES "SPiN" STA-PUT NIBS ON BACKING TO LIMIT SLIPPING
- MADE IN USA
- AVAILABLE IN BLACK, GREY AND TAN TO COMPLIMENT ALL INTERIORS

HUSKY GEARBOX[®]

VEHICLE INTERIOR STORAGE SYSTEMS

- ORGANIZE & STORE LOOSE ITEMS OUT OF SIGHT
- LARGE CAPACITY WITH REMOVABLE DIVIDERS
- FITS SPECIFICALLY UNDER SECOND SEAT
- NOISE REDUCING IMPACT RESISTANT SURFACE
- BLACK TEXTURED FINISH FOR A FACTORY LOOK



07-09 SILVERADO EXT CAB
PART #09011



02-09 RAM QUAD CAB
PART #09401



09-10 F150 SUPER CREW
PART #09241



| MAKE | YEAR | MODEL | Husky GearBox PART # |
|-----------|---------|--|-------------------------|
| CHEVY/GMC | 2007-09 | AVALANCHE | 09271 |
| | 99-2007 | SILVERADO/SIERRA EXT CAB (CLASSIC) | 09021 |
| | 2007-09 | SILVERADO/SIERRA CREW CAB | 09001 |
| | 2007-09 | SILVERADO/SIERRA EXT CAB | 09011 |
| DODGE | 2002-09 | RAM QUAD CAB W/O OPTIONAL FOLDING FLAT LOAD FLOOR | 09401 |
| FORD | 2004-08 | F150 SUPER CAB/CREW W/O UNDERSEAT SUBWOOFER | 09201 |
| | 2009-10 | F150 SUPER CAB WITHOUT SUBWOOFER | 09261 |
| | 2009-10 | F150 SUPER CREW WITHOUT REAR SUBWOOFER | 09241 |
| | 2009-10 | F150 SUPER CREW WITH REAR SUBWOOFER | 09251 |
| | 99-2010 | F250-550 REG CAB | 09221* |
| | 2000-07 | F250-550 CREW CAB WITH FULL REAR BENCH SEAT | 09221* |
| | 2000-10 | F250-550 SUPER CAB (INSTALLS UNDER REAR SEAT) | 09211 |
| | 2005-10 | F250-550 CREW CAB WITH 60/40 SPLIT REAR BENCH SEAT | 09231 |
| TOYOTA | 2007-10 | TUNDRA DOUBLE CAB WITHOUT OEM SUBWOOFER | 09501 |

| Make | Year | Model | Part # |
|-----------|-------|--|--------|
| Chevy/GMC | 07-09 | Silverado/Sierra & HD Series (New Body Style) | 15240 |
| | 99-07 | Silverado/Sierra (F/S) & HD Series | 15230 |
| | 88-00 | CK 1500 Series (Not Center Handle Style) | 15220 |
| | 92-00 | CK 2500/3500 Series Crew Cab & 3500 Series | |
| Dodge | 2009 | RAM 1500 Series | 15340 |
| | 03-09 | RAM 2500/3500 Series | 15330 |
| | 02-08 | RAM 1500 Series | 15330 |
| | 94-02 | RAM (2500/3500 Series Old Body Style) | 15320 |
| | 94-01 | RAM (1500 Series Old Body Style) | 15320 |
| Ford | 09-10 | F-150 | 15160 |
| | 04-08 | F-150 Includes F-150 Super Crew | 15150 |
| | 97-04 | F-150 Series & Lt Duty F250 & 04 Heritage Edition Does Not fit Super Crew | 15130 |
| | 99-10 | F-250 HD & F-350 Super Duty | 15130 |
| | 87-98 | F-250/350 Series (F/S) Not Center Handle Style | 15120 |
| | 87-96 | F-150 Series (Full-Size) Not Center Handle Style | 15120 |

ALUMINUM PRODUCTS



5TH WHEEL TAILGATE

- HEAVY DUTY LOUVERED DESIGN REDUCES WIND RESISTANCE
- HALF THE WEIGHT OF MOST FACTORY TAILGATES
- A MULTI COAT PROCESS THAT PROVIDES A SMOOTH CONSISTENT FINISH THAT IS UV RESISTANT AND EASY TO CLEAN

www.huskyliners.com • www.customtruckpartsinc.com

HUSKYLINERS®

CUSTOM MOLDED MUD GUARDS

| Make | Year | Model | Front | Rear | |
|---------------|----------------|--|---|-------|-------|
| Cadillac | 07-09 | Escalade w/o pwr assist steps & w/o flares | 56731 | 57781 | |
| | 07-09 | Escalade ESV w/o pwr assist steps & w/o flares | 56731 | 56781 | |
| | 07-09 | Escalade EXT w/o pwr assist steps & w/o flares | 56731 | 56761 | |
| Chevy/GMC | 07-09 | Avalanche w/o pwr assist steps & w/o flares | 56731 | 56761 | |
| | 04-09 | Colorado/Canyon w/o flares | 56701 | 57701 | |
| | 04-09 | Colorado/Canyon w/OEM mini flares | 56721 | 57721 | |
| | 04-09 | Colorado/Canyon w/OEM large flares | 56811 | 56811 | |
| | 02-08 | Envoy/Envoy XL/Envoy XUV | 56341 | 57341 | |
| | 05-09 | Equinox | 56391 | 57391 | |
| | 07-09 | Silverado (new body style) w/o flares | 56801 | 57801 | |
| | (Rear Dually) | 07-09 | Silverado HD Series (new body style) | 56791 | 57841 |
| | (Rear Dually) | 07-09 | Sierra/Sierra Denali (new body) w/o flares | 56801 | 57801 |
| | (Rear Dually) | 07-09 | Sierra HD Series (new body style) | 56801 | 57841 |
| | (Rear Dually) | 99-06 | Silverado/Sierra & 07 Classic without flares Sportside/Stepside | 56251 | 57241 |
| | | 99-06 | Silverado/Sierra & 07 Classic w/OEM flares | 56211 | 57211 |
| | | 01-06 | Silverado/Sierra/HD Series & 07 Classic | 56211 | 57351 |
| | | 07-09 | Suburban/Yukon XL without flares | 56731 | 57761 |
| | | 00-06 | Suburban/Yukon XL & Tahoe Yukon w/o flares with OEM flares | 56251 | 57241 |
| | | | | 56211 | 57211 |
| | | 07-09 | Tahoe/Yukon without flares | 56731 | 57731 |
| | | 2009 | Tahoe LTZ without power assist steps | 56731 | 57781 |
| | | 07-09 | Yukon Denali w/o pwr assist steps & w/o flares | 56731 | 57781 |
| | | 07-09 | Yukon XL Denali w/o pwr assist steps & w/o flares | 56731 | 56781 |
| | | 07-09 | Z-71 Avalanche w/OEM lrg flares/lower body cladding | 56821 | 56831 |
| | 07-09 | Z-71 Suburban w/OEM lrg flares/lower body cladding | 56821 | 57821 | |
| | 07-09 | Z-71 Tahoe w/OEM lrg flares/lower body cladding | 56821 | 57831 | |
| 06-09 | Trailblazer LT | 56741 | 57741 | | |
| Chrysler | 07-09 | Aspen | 56131 | 57131 | |
| | 05-10 | Dakota | 56091 | 57091 | |
| Dodge | 07-09 | Durango | 56131 | 57131 | |
| | 2009 | RAM 1500 w/o flares | 56151 | 57151 | |
| (Rear Dually) | 2009 | RAM 1500 w/OEM flares | 56161 | 57161 | |
| | 06-09 | RAM Mega Cab Truck Full Size | 56071 | 57121 | |
| (Rear Dually) | 03-09 | RAM 2500/3500 & 02-08 1500 Series Truck | 56071 | 57061 | |
| | 03-09 | RAM Truck Full Size (New Body Style) | 56071 | 57071 | |
| | 94-01 | RAM 1500 & 94-02 2500/3500 Series | 56001 | 56001 | |
| Ford | 08-09 | Escape/Mariner with running boards | 56661 | 57661 | |
| | 08-09 | Escape/Mariner without running boards | 56671 | 57661 | |
| | 07-10 | Expedition won't work w/4x4 Off Road Pkg/Limited | 56631 | 57631 | |
| | 07-10 | Expedition EL accomodates OEM running boards | 56651 | 57651 | |
| | 03-06 | Expedition | 56541 | 57541 | |
| | 06-10 | Explorer (except XLS) w/o power running boards | 56611 | 57611 | |
| | 07-09 | Explorer Sport Trac | 56621 | 57621 | |
| | 04-10 | F-150 PU Flareside/Styleside & 06-08 Lincoln Mark LT - w/OEM flares & OEM running boards | 56591 | 57591 | |
| | 04-10 | F-150 PU w/o flares & w/o running boards | 56601 | 57601 | |
| | 04-10 | F-150 PU w/o flares & w/OEM run. boards | 56591 | 57601 | |
| | 97-03 | F-150 PU & 04 Heritage Edition w/OEM flares | 56411 | 57411 | |
| | 97-03 | F-150 PU & 04 Heritage Edition w/o flares | 56421 | 57421 | |
| | 01-03 | F-150 Super Crew PU w/OEM flares/running boards | 56531 | 57511 | |
| | 01-03 | F-150 Super Crew PU w/OEM flares, w/o running boards | 56411 | 57511 | |
| | 01-03 | F-150 Super Crew PU without flares | 56421 | 57531 | |
| | 99-10 | F-250-350 Super Duty PU with OEM flares | 56511 | 57581 | |
| | 08-10 | F-250-350 Super Duty PU w/o OEM flares | 56641 | 57401 | |
| | (Rear Dually) | 99-10 | F-250-350 Super Duty PU with OEM flares | 56511 | 57451 |
| | (Rear Dually) | 08-10 | F-250-350 Super Duty PU w/o OEM flares | 56641 | 57451 |
| | Hummer | 03-09 | H2/H2 SUT | 56361 | 57361 |
| | | 06-09 | H3 | 56711 | 57711 |
| | | 2009 | H3T | 56711 | 57851 |
| | Jeep | 99-04 | Grand Cherokee Freedom/Laredo | 56011 | 57011 |
| 99-04 | | Grand Cherokee Limited/SE-Special Edition | 56021 | 57021 | |
| 05-10 | | Grand Cherokee w/Hemi 5.7L | 56101 | 57111 | |
| 05-10 | | Grand Cherokee w/o Hemi 5.7L | 56101 | 57101 | |
| 07-10 | | Wrangler/Wrangler Unlimited | 56141 | 57141 | |
| Toyota | 07-09 | Tundra | 56911 | 57911 | |
| Universal | ALL | Large Size (Guard is: 11-11.75" x 17.63") | 56331 | 56331 | |
| | ALL | Medium Size (Guard is: 9-9.75" x 15.75") | 56261 | 56261 | |

NOTE: HUSKY LINERS® MUD GUARDS ARE DESIGNED TO FIT VEHICLES EQUIPPED WITH MOST FACTORY WHEEL/TIRE PACKAGES. CHECK TO MAKE SURE YOUR MUD GUARDS DO NOT INTERFERE WITH TIRE TURNING CLEARANCE. DO NOT OPERATE VEHICLE WITH INTERFERENCE AS DAMAGE MAY OCCUR.

CUSTOM MOLDED MUD GUARDS

- PROVIDE ENHANCED STYLING AND PREVENT DAMAGE TO YOUR VEHICLE AND THE VEHICLES AROUND YOU.
- KEEP MUD, SNOW AND ICE OFF YOUR RUNNING BOARDS.
- ENGINEERED TO PERFECTLY COUNTER FENDERS AND BODY PANELS PROVIDING A CUSTOM FIT FOR EVERY VEHICLE.
- MANUFACTURED FROM A DURABLE IMPACT RESISTANT THERMOPLASTIC TO ENSURE THE MUD GUARD WILL LAST FOR THE LIFE OF YOUR VEHICLE.
- INCLUDES HUSKY SHIELDS PAINT PROTECTION FILM AND MUD GUARDS THAT CONTACT FACTORY PAINT.
- ALL FASTENERS AND INSTRUCTIONS INCLUDED FOR AN EASY INSTALLATION.

FRONT MUD GUARD



DUALY MUD GUARD



HUSKY SHIELD

A REVOLUTIONARY PAINT PROTECTION SYSTEM

- PROTECT YOUR VEHICLE'S PAINT FROM ROCK CHIPS, BUGS AND SCRATCHES WITH HUSKY SHIELD A CLEAR PAINT PROTECTION FILM
- OUR CLEAR PAINT FILM IS VIRTUALLY INVISIBLE AND WILL NOT DETRACT FROM YOUR VEHICLE'S STYLING
- HUSKY SHIELD PAINT PROTECTION WILL NOT YELLOW AND IS UV STABLE, THIS ALLOWS YOUR PAINT TO AGE NATURALLY
- THE EASIEST TO INSTALL PAINT PROTECTION FILM ON THE MARKET



| MAKE | YEAR | MODEL | Husky Shield only PART# | Husky Shield & 4oz install kit |
|-----------|-------------------|--|----------------------------|-----------------------------------|
| CADILLAC | 2007-09 | ESCALADE/ESCALADE EXV/ESCALADE EXT | 06001 | 06009 |
| | 2004-08 | SRX | 06041 | 06049 |
| CHEVY/GMC | 2005-09 | COBALT | 06271 | 06279 |
| | 2004-09 | COLORADO | 06291 | 06299 |
| | 2006-10 | HHR | 06281 | 06289 |
| | 2006-10 | IMPALA | 06251 | 06259 |
| | 2008-09 | MALIBU | 06261 | 06269 |
| | 2007-09 | SIERRA/SIERRA HD SERIES | 07211 | 07219 |
| | 2007-09 | SILVERADO | 06201 | 06209 |
| | 2007-09 | SILVERADO HD SERIES PU | 06231 | 06239 |
| | 2007-09 | SUBURBAN/TAHOE & AVALANCHE | 06211 | 06219 |
| | 2008-09 | TAHOE HYBRID | 06301 | 06309 |
| | 2006-09 | TRAILBLAZER | 06221 | 06229 |
| | 2007-09 | YUKON/YUKON XL | 07201 | 07209 |
| | 2007-09 | YUKON DENALI/YUKON XL DENALI | 07201 | 07209 |
| | DODGE | 2009 | RAM 1500 | 06651 |
| 2006-08 | | RAM 1500 (06-09 2500/3500 SERIES) | 06601 | 06609 |
| FORD | 2007-10 | EDGE | 06861 | 06869 |
| | 2008-10 | ESCAPE | 06851 | 06859 |
| | 2007-10 | EXPEDITION/EXPEDITION EL | 06801 | 06809 |
| | 2006-10 | EXPLORER | 06841 | 06849 |
| | 2009-10 | F150 PU | 06941 | 06949 |
| | 2004-08 | F150 PU | 06811 | 06819 |
| | 2008-09 | FOCUS | 06911 | 06919 |
| | 2006-09 | FUSION | 06871 | 06879 |
| | 2005-09 | MUSTANG | 06921 | 06929 |
| | 2007-09 | MUSTANG GT500 | 06931 | 06939 |
| | 2006-09 | RANGER | 06901 | 06909 |
| | 2002-07 | SUPER DUTY | 06821 | 06829 |
| | 2008-10 | SUPER DUTY | 06831 | 06839 |
| | 2008-09 | TAURUS | 06881 | 06889 |
| 2008-09 | TAURUS X | 06891 | 06899 | |
| HONDA | 2008-10 | ACCORD | 07521 | 07529 |
| | 2006-08 | CIVIC | 07531 | 07539 |
| JEEP | 2007-09 | WRANGLER | 06401 | 06409 |
| | 2007-09 | WRANGLER - SAHARA PACKAGE (OEM PAINTED BUMPER AND FLARES) | 16401 | 16409 |
| LINCOLN | 2007-09 | NAVIGATOR/NAVIGATOR L | 07401 | 07409 |
| NISSAN | 2004-10 | ARMADA/TITAN | 07601 | 07609 |
| TOYOTA | 2007-10 | CAMRY | 07821 | 07829 |
| | 2009-10 | COROLLA | 07831 | 07839 |
| | 2007-09 | FJ CRUISER | 07911 | 07919 |
| | 2008-09 | HIGHLANDER | 07891 | 07899 |
| | 2007-09 | PRIUS | 07841 | 07849 |
| | 2009 | RAV4 | 07881 | 07889 |
| | 2008 | SEQUOIA | 07811 | 07819 |
| | 2005-09 | TACOMA | 07801 | 07809 |
| 2007-10 | TUNDRA (NEW BODY) | 07811 | 07819 | |