

# Suspension Enhancement Systems



# TIMBREN



| Make / Model<br><i>(*) Partial Listing Only</i>                        | Year |      | Location     | Axle      | Timbren SES | Price Code | NO DRILL |
|--|------|------|--------------|-----------|-------------|------------|----------|
|  | From | To   | Front / Rear | 2WD / 4WD | Part #      |            |          |
| <b>CHEVROLET- GENERAL MOTORS PICKUPS, VANS &amp; MOTOR HOMES, SUVs</b> |      |      |              |           |             |            |          |
| COLORADO CANYON  | 2004 | 2010 | Rear         | 2/4WD     | GMRCC       | A          | No Drill |
| S10, S15, SONOMA   | 2000 | 2004 | Rear         | 2/4WD     | GMRS10B     | A          | No Drill |
| S10, S15, SONOMA   | 1975 | 1999 | Rear         | 2/4WD     | GMRS10A     | A          | No Drill |
| 1500 SIERRA, SILVERADO, DENALI   | 1999 | 2008 | Rear         | 2/4WD     | GMRCK15S    | A          | No Drill |
| 1500 SIERRA, SILVERADO, DENALI   | 1988 | 1999 | Rear         | 2WD       | GMRC25HD    | A          | No Drill |
| 1500 SIERRA, SILVERADO, DENALI   | 1988 | 1999 | Rear         | 4WD       | GMRCK25     | A          | No Drill |
| 2500 SIERRA, SILVERADO   | 1999 | 2010 | Rear         | 2/4WD     | GMRCK25S    | A          | No Drill |
| 2500 SIERRA, SILVERADO   | 1988 | 1999 | Rear         | 4WD       | GMRCK25     | A          | No Drill |
| 3500 SIERRA, SILVERADO   | 1988 | 2010 | Rear         | 2/4WD     | GMRCK35S    | B          | No Drill |
| AZTEK, RENDEZ-VOUS, Except air shocks                                  | 2001 | 2009 | Rear         | 4WD       | GMRREN (p)  | A          | No Drill |
| ASTRO, SAFARI - Steel rear springs                                     | 1996 | 2005 | Rear         | 2/4WD     | GMASTB      | A          | No Drill |
| ASTRO, SAFARI - Composite rear springs                                 | 1985 | 1995 | Rear         | 2WD       | GMASTR      | A          | No Drill |
| UPLANDER, TERRAZA, MONTANA, RELAY, VENTURE, MONTANA-SV6                | 2005 | 2010 | Rear         | 2WD       | GMRAZT (p)  | A          | No Drill |
| UPLANDER, TERRAZA, MONTANA, RELAY, VENTURE, MONTANA-SV6                | 2005 | 2010 | Rear         | 4WD       | GMRUPL (p)  | A          | No Drill |
| G/H1500, G/H2500-CHEVY, EXPRESS, SAVANA                                | 1996 | 2010 | Rear         | 2/4WD     | GMRG25C     | A          | No Drill |
| G3500 VAN  | 1996 | 2010 | Rear         | 2/4WD     | GMRG35      | B          | No Drill |
| G3500 MOTOR HOME   | 1975 | 2010 | Rear         | 2WD       | GMRG30      | B          | No Drill |
| SATURN VUE, EQUINOX, TORRENT   | 2002 | 2010 | Rear         | 2/4WD     | GMRVUE (p)  | A          | No Drill |
| TRAIL-BLAZER, ENVOY, BRAVADA, RAINIER                                  | 2002 | 2010 | Rear         | 2/4WD     | GMRETB      | A          | No Drill |
| DENALI, YUKON  | 2002 | 2010 | Rear         | 2WD       | GMRY54      | A          | No Drill |
| SUBURBAN, YUKON XL 1500  | 2000 | 2010 | Rear         | 2/4WD     | GMRY54      | A          | No Drill |
| SUBURBAN, YUKON XL 2500  | 2000 | 2010 | Rear         | 2/4WD     | GMRSB4S     | A          | No Drill |
| SUBURBAN, JIMMY, K-BLAZER - Full size                                  | 1993 | 1999 | Rear         | 2WD       | GMRSB       | A          | No Drill |
| SUBURBAN, JIMMY, K-BLAZER - Full size                                  | 1993 | 1999 | Rear         | 4WD       | GMRSB4      | A          | No Drill |

Note: (p) Professional Installation



Typical Timbren SES kit installed

## Customers say:

*"I installed the Timbren's in about 45 minutes...  
With the Timbrens installed I never looked back.  
No maintenance, no worry."  
JM - OH.*

*"I have used both air bags and Timbrens and  
I will never go back to the air bag. Nothing to  
worry about once they are installed and they  
work great without changing the factory ride."  
RT - TX.*



[www.timbren.com](http://www.timbren.com) • [www.customtruckpartsinc.com](http://www.customtruckpartsinc.com)



- ✓ Easy to install
- ✓ Trouble Free
- ✓ Maintenance Free
- ✓ Bolt-on Kits - No Drilling



Recommended for all Trucks,  
Pickups, Vans, SUVs,  
Heavily Loaded or Off-Road

| Make / Model<br><small>(*) Partial Listing Only</small> | Year |      | Location        | Axle      | Timbren SES | Price Code | NO<br>DRILL |  |
|---|------|------|-----------------|-----------|-------------|------------|-------------|--|
|   | From | To   | Front /<br>Rear | 2WD / 4WD | Part #      |            |             |  |
| <b>DODGE</b>  |      |      |                 |           |             |            |             |  |
| <b>PICKUPS, VANS &amp; MOTOR HOMES, SUVs</b>            |      |      |                 |           |             |            |             |  |
| DAKOTA  | 2005 | 2010 | Rear            | 4WD       | DDR05       | A          | No Drill    |  |
| DAKOTA  | 1997 | 2004 | Rear            | 2/4WD     | DDR00       | A          | No Drill    |  |
| RAM 1500 Excluding QUAD CAB                             | 2009 | 2010 | Rear            | 2/4WD     | DR1500DS    | A          | No Drill    |  |
| RAM 1500 QUAD CAB                                       | 2009 | 2010 | Rear            | 2/4WD     | DR1500DQ    | A          | No Drill    |  |
| RAM 1500 Regular & QUAD CAB                             | 2006 | 2008 | Rear            | 2/4WD     | DR1525H4    | A          | No Drill    |  |
| RAM 1500 MEGACAB  | 2003 | 2009 | Rear            | 2/4WD     | DR2500CA    | A          | No Drill    |  |
| RAM 2500  | 2003 | 2010 | Rear            | 2/4WD     | DR2500CA    | A          | No Drill    |  |
| RAM 3500  | 2003 | 2010 | Rear            | 2/4WD     | DR3500CA    | B          | No Drill    |  |
| CARAVAN, VOYAGER, TOWN & COUNTRY                        | 2008 | 2010 | Rear            | 2WD       | DVRRRT      | A          | No Drill    |  |
| CARAVAN, VOYAGER, TOWN & COUNTRY                        | 1996 | 2007 | Rear            | 2WD       | DVR05096    | A          | No Drill    |  |
| SPRINTER 2500   | 2007 | 2009 | Rear            | 2WD       | MBRSP25A    | B          | No Drill    |  |
| SPRINTER 2500   | 2002 | 2006 | Rear            | 2WD       | MBRSP25     | B          | No Drill    |  |
| SPRINTER 3500 MOTOR HOME                                | 2007 | 2009 | Rear            | 2WD       | MBRSP35A    | B          | No Drill    |  |
| SPRINTER 3500   | 2002 | 2006 | Rear            | 2WD       | MBRSP35     | B          | No Drill    |  |
| B 300/350 VAN, MOTOR HOME                               | 1975 | 2004 | Rear            | 2WD       | DVR350R     | B          | No Drill    |  |
| JEEP JK, WRANGLER                                       | 2007 | 2010 | Rear            | 4WD       | JRJK        | A          | No Drill    |  |
| JEEP TJ, WRANGLER                                       | 1997 | 2006 | Rear            | 4WD       | JFTJ (p)    | A          | No Drill    |  |
| JEEP LIBERTY  | 2002 | 2010 | Rear            | 4WD       | JRL4 (p)    | A          | No Drill    |  |
| JEEP GRAND CHEROKEE, COMMANDER                          | 2005 | 2010 | Rear            | 4WD       | JRC04       | A          | No Drill    |  |
| <b>FORD</b>   |      |      |                 |           |             |            |             |  |
| <b>PICKUPS, VANS &amp; MOTOR HOMES, SUVs</b>            |      |      |                 |           |             |            |             |  |
| RANGER  | 1983 | 2010 | Rear            | 2WD       | FRR050A     | A          | No Drill    |  |
| RANGER  | 1983 | 2007 | Rear            | 4WD       | FRR0504A    | A          | No Drill    |  |
| F150  | 2009 | 2010 | Rear            | 4WD       | FR1504D     | A          | No Drill    |  |
| F150  | 2004 | 2010 | Rear            | 2WD       | FR1502D     | A          | No Drill    |  |
| F150 Excluding HERITAGE                                 | 2004 | 2008 | Rear            | 4WD       | FR150D      | A          | No Drill    |  |
| F150  | 1997 | 2003 | Rear            | 2/4WD     | FR1525HD    | A          | No Drill    |  |
| F250 SUPER DUTY   | 2005 | 2010 | Rear            | 2/4WD     | FR250SDF    | A          | No Drill    |  |
| F250 SUPERDUTY, F250HD                                  | 1970 | 1998 | Rear            | 4WD       | FR250SDE    | A          | No Drill    |  |
| F350 SUPER DUTY   | 2005 | 2010 | Rear            | 2/4WD     | FR350SDF    | B          | No Drill    |  |
| F350 SUPER DUTY   | 1999 | 2004 | Rear            | 2/4WD     | FR350SDE    | B          | No Drill    |  |
| F450 SUPER DUTY PICKUP                                  | 2008 | 2010 | Rear            | 2/4WD     | FRSDP       | C          | No Drill    |  |
| AEROSTAR  | 1986 | 2003 | Rear            | 2/4WD     | FAR001      | A          | No Drill    |  |
| MERCURY VILLAGER  | 1993 | 2003 | Rear            | 2WD       | FVR001      | A          | No Drill    |  |
| WINDSTAR - except load leveler option, FREESTAR         | 1994 | 2007 | Rear            | 2WD       | FRWIN       | A          | No Drill    |  |
| E150  | 1987 | 2010 | Rear            | 2WD       | FER15087    | A          | No Drill    |  |
| E250,E350 Including MOTOR HOME                          | 1987 | 2010 | Rear            | 2WD       | FER35092B   | B          | No Drill    |  |
| F53 - leaf spring front suspension MOTOR HOME           | 2002 | 2010 | Front           | 2WD       | FFF53B      | C          | No Drill    |  |
| F53 - leaf spring front suspension MOTOR HOME           | 1989 | 2010 | Rear            | 2WD       | FRF53A      | C          | No Drill    |  |
| ESCAPE  | 2001 | 2010 | Rear            | 2/4WD     | FRESC (p)   | A          | No Drill    |  |
| EXPEDITION - except air suspension                      | 1997 | 2002 | Rear            | 2/4WD     | FREXP4      | A          | No Drill    |  |
| EXCURSION   | 2000 | 2005 | Rear            | 4WD       | FREXC4      | A          | No Drill    |  |

Note: (p) Professional Installation



**LIFETIME SATISFACTION GUARANTEE WARRANTY**

**Best Choice**

- ✓ Eliminate Sag & Sway
- ✓ Optimize Load Handling
- ✓ Improve Roll Stability
- ✓ Cushion Road Shocks
- ✓ Improve Ride Comfort

**You can trust TIMBREN SES for the Best Ride, Best Handling vehicles.**

| Make / Model<br>(* Partial Listing Only)                | Year                       |      | Location     | Axle      | Timbren SES | Price Code | NO DRILL |
|---|----------------------------|------|--------------|-----------|-------------|------------|----------|
|   | From                       | To   | Front / Rear | 2WD / 4WD | Part #      |            |          |
| <b>FREIGHTLINER</b>                                     | <b>MOTOR HOME CHASSIS</b>  |      |              |           |             |            |          |
| "V" SERIES, D400  |                            |      | Rear         |           | OSHRV       | E          | No Drill |
| <b>HONDA</b>  | <b>PICKUPS, VANS</b>       |      |              |           |             |            |          |
| ODYSSEY   | 2002                       | 2010 | Rear         | 2WD       | HR0D2 (p)   | A          | No Drill |
| <b>MAZDA</b>  | <b>PICKUPS, VANS</b>       |      |              |           |             |            |          |
| B2300, B2500, B3000, B4000                              | 2008                       | 2010 | Rear         | 2/4WD     | FRR050A     | A          | No Drill |
| B2300, B2500, B3000, B4000                              | 1994                       | 2007 | Rear         | 4WD       | FRR0504A    | A          | No Drill |
| MPV   | 2000                       | 2006 | Rear         | 2WD       | MRMPV       | A          | No Drill |
| <b>NISSAN</b>   | <b>PICKUPS, VANS, SUVs</b> |      |              |           |             |            |          |
| FRONTIER, TITAN   | 2004                       | 2010 | Rear         | 2WD       | TORTUN4     | A          | No Drill |
| TITAN   | 2004                       | 2010 | Rear         | 4WD       | NRTTN       | A          | No Drill |
| XTERRA  | 2005                       | 2010 | Rear         | 2/4WD     | JRCO1       | A          | No Drill |
| XTERRA  | 2000                       | 2004 | Rear         | 4WD       | NRXT4       | A          | No Drill |
| ARMADA, INFINITY / QX56                                 | 2004                       | 2010 | Rear         | 4WD       | NRARM       | A          | No Drill |
| <b>TOYOTA</b>   | <b>PICKUPS, VANS, SUVs</b> |      |              |           |             |            |          |
| TACOMA, TACOMA S & X-RUNNER with 3 Leaf OEM Rear        | 2005                       | 2010 | Rear         | 2WD       | TORXR       | A          | No Drill |
| TACOMA, TACOMA S & X-RUNNER with 3 Leaf OEM Rear        | 2005                       | 2010 | Rear         | 4WD       | TORTUN4L    | A          | No Drill |
| TACOMA PRE-RUNNER                                       | 1998                       | 2004 | Rear         | 2WD       | TORTAC4A    | A          | No Drill |
| TUNDRA  | 2000                       | 2010 | Rear         | 2/4WD     | TORTUN4     | A          | No Drill |
| SIENNA  | 2004                       | 2009 | Rear         | 2/4WD     | TORSEN04    | A          | No Drill |
| SEQUOIA excluding air bags                              | 2008                       | 2010 | Rear         | 2/4WD     | TORSEQ1     | A          | No Drill |
| SEQUOIA   | 2001                       | 2007 | Rear         | 2/4WD     | TORSEQ      | A          | No Drill |
| FJ CRUISER  | 2007                       | 2010 | Rear         | 2/4WD     | TORSEQ      | A          | No Drill |
| LANDCRUISER   | 1985                       | 1997 | Rear         | 4WD       | TORLC1      | A          | No Drill |
| <b>WORKHORSE</b>  | <b>MOTOR HOME CHASSIS</b>  |      |              |           |             |            |          |
| P42, W20, W22 - with "I" beam front axle (leaf springs) | 2000                       | 2007 | Front        |           | WFRW22      | C          | No Drill |
| P42, W20, W22 - with "I" beam front axle (leaf springs) | 2000                       | 2007 | Rear         |           | WRW22       | C          | No Drill |

Note: (p) Professional Installation



## Easy Bolt-On

It's this easy!  
Just remove the bump stop from the frame



## No Drilling

Mount Aeon® hollow rubber spring to bracket and assemble to frame



[www.timbren.com](http://www.timbren.com) • [www.customtruckpartsinc.com](http://www.customtruckpartsinc.com)